

View this page with this edge up.

This illustration shows the use of a plinth block at the intersection of the casing and base. This is a very traditional example of treating the intersection. An alternative would be to use a casing thick enough for the base and shoe to die behind thus eliminating the need for a plinth. Shown here are the AB203 base, AB118 casing and AB68 plinth.

